

Installation Procedure for All Chelmstone Ornamental Planters

Important Note

After correct installation of a planter, it is crucial that children do not hang from or play near to the installation in case one of the components becomes dislodged from the assembly and falls onto a person.

As an extra safety precaution until the adhesive is fully set the area should be barricaded to prevent children entering the pond area.

Children must be supervised when they are near to the planter.

Installation

All elements of the planter assembly must be stuck together using a suitable adhesive. We recommend the use of SIKAflex-11FC as an adhesive for this application.

Place the Ornament or Planter on a solid level surface.

It may be necessary to test place each of the elements of the planter assembly first before applying adhesive to the mating surfaces. When glueing parts together ensure that the surfaces to be glued are free of loose sand or concrete and that the surfaces are dry and clean of oils or detergents.

Working from the bottom most element of the assembly, glue each piece to its mating part until all parts are fixed together.

Ensure that the assembly is not bumped or moved once positioning correctly. Leave to dry for 24 hours before planting or filling with water.

If any of Chelmstone's ornaments are to be used as Water Features, they will need to be sealed and waterproofed beforehand.

It is our recommendation that an experienced installer is called upon to install all planters and ornamental features.