

Pier and Wall Capping Installation Procedure

- Pier caps and wall caps can be glued down using either a mortar mix or cement based tile adhesive (as per the manufacturer's instructions).
- Mix 2 litres latex bonding agent (Kemcrete, weldcrete), 4kg neat cement and 2 Litres of Water, then mix thoroughly. Use this mix to brush on the underside of the capping.
- Bed allowing 8-10 mm joints using a string line to keep line's straight.
- If the capping butts into any other surface use an expansion joint material, such as Sikaflex.
- Allow for expansion joints every 4 metres as per industry standards.
- Make sure any mortar or other material is sponged off the product immediately to prevent staining.
- Joints can be grouted using Chelmstone's colour matching grout, or a mix of fine white sand and off-white cement.
- It is our recommendation that an experienced installer is called upon to install all pier and wall capping.